


# FLYWHEEL HOUSING AND REAR MOUNTS



# FLYWHEEL HOUSING AND REAR MOUNTS

REF	PART NO.	QTY	DESCRIPTION	NOTES
1	3857846	1	Flywheel housing	
2	3854604	1	Cover	
3	3852834	1	Gasket, Flywheel cover	Part of engine gasket kit
4	3852832	1	Hose, Flywheel hsg	
5	3852421	7	Screw, Flywheel cover	
6	3853392	2	Screw, Flywheel hsg to engine	
	3853547	1	Screw, Reservoir and flywheel hsg to engine	
7	3852002	2	Lock washer, Ground stud, flywheel hsg	
8	3852058	2	Washer, Ground stud, flywheel hsg	
10	959968	4	Screw, Rear mount to transom plate	
11	3853806	2	Rubber cushion, Transom plate	
12	3852155	4	Washer, Rear mount to transom plate	
13	3850930	2	Screw, Rear mount	
14	3850929	2	Nut, Rear mount	
15	3852540	2	Washer, Rear mount to flywheel hsg	
16	3852539	2	Nut, Rear mount	
17	3852622	2	Washer, Rear mount	
20	3852542	2	Washer, Rear mount	
21	3852483	2	Stud, Flywheel housing to engine	Ground
22	3852065	2	Nut, Terminal to ground stud, flywheel hsg	
23	3852070	1	Washer, Ground stud, fl heel hs	Starboard