


Parts List

| Ref | Class | Part | Description | Qty | Comment | Footnote |
|-----|-------|-----------|-----------------------|-----|-------------------------|----------|
| - | 84 | 861262A 1 | WIRING HARNESS-ENGINE | 1 | (SN-0L304599 and Below) | 1 |
| | 84 | 861159T 1 | WIRING HARNESS-ENGINE | 1 | (SN-0L304600 and Up) | |



- 1 - Fuel Pump
- 2 - Throttle Body
- 3 - Distributor
- 4 - Coil
- 5 - Electronic Spark Control (KS) Module
- 6 - Data Link Connector (DLC)
- 7 - Manifold Absolute Pressure (MAP) Sensor
- 8 - Knock Sensor
- 9 - Idle Air Control (IAC)
- 10- Throttle Position (TP) Sensor
- 11- Engine Coolant Temperature (ECT) Sensor
- 12- Electronic Control Module (ECM)
- 13- Fuel Pump Relay
- 14- Ignition/System Relay
- 15- Fuse (15 Amp) Fuel Pump
- 16- Fuse (15 Amp) ECM/DLC/Battery
- 17- Fuse (10 Amp) ECM/Injector/Ignition/Knock Module
- 18- Harness Connector To Starting/Charging Harness
- 19- Positive (+) Power Wire To Engine Circuit Breaker